



DALLAS 300

Par LED Spotlight 30 x 10W RGBW 4-in-1
Foco Par LED 30 x 10W RBGW 4 en 1

INDEX / ÍNDICE**ENGLISH**

WELCOME TO AUDIBAX.....	1
SAFETY INSTRUCTIONS.....	1
IMPORTANT INFORMATION.....	2
PACKAGE CONTENT.....	3
PRODUCT DESCRIPTION.....	3
DISPOSAL.....	3

ESPAÑOL

BIENVENIDOS A AUDIBAX.....	4
INSTRUCCIONES DE SEGURIDAD.....	4
INFORMACIÓN IMPORTANTE.....	5
CONTENIDO DEL PAQUETE.....	6
DESCRIPCIÓN DEL PRODUCTO.....	6
RECICLAJE.....	6

DMX

DMX (English).....	7
DMX (Español).....	8

WELCOME TO AUDIBAX

Thank you very much for choosing Audibax. We hope you enjoy your new product.

It has been developed and designed paying attention to the smallest details, with quality control with European standards supervised by our great team of professional technicians, who work every day to offer our customers the best quality.

We make sure that every Audibax product is built to last long. All our references are made with long lasting materials and our specialists are dedicated to constantly doing quality controls to guarantee the best result.

Please read carefully this manual in order to use your Audibax product in the best way. Do not hesitate to visit our website for further information: www.audibax.com


SAFETY INSTRUCTIONS

GENERAL INFORMATION

- It is important to read and follow the instructions carefully.
- Keep all information and instructions in a secure location.
- Always follow the instructions provided.
- Take note of all safety warnings and never remove them from the equipment.
- Use the equipment only as intended and for its intended purpose.
- Ensure that the stands and/or mounts used are sufficiently stable and compatible for fixed installations. Wall mounts should be properly installed and secured, and the equipment should be installed securely to prevent falls.
- When installing the equipment, be sure to observe the relevant safety regulations in your country.
- Do not install or operate the equipment near sources of heat, such as radiators, heat registers, or ovens, and ensure that it is always cooled sufficiently and cannot overheat.
- Do not place sources of ignition, such as burning candles, on the equipment.
- Keep ventilation slits unobstructed.
- For equipment designed for indoor use only should not be used near water, flammable materials, fluids, or gases. Special outdoor equipment should be used in accordance with the manufacturer's instructions.
- Ensure that no dripping or splashed water can enter the equipment and do not place containers filled with liquids on the equipment.
- Prevent objects from falling into the equipment.
- Use the equipment only with recommended accessories intended by the manufacturer.
- Do not attempt to open or modify the equipment.
- Check all cables after connecting the equipment to prevent accidents or damage due to tripping hazards.
- During transport, take steps to prevent the equipment from falling and causing damage or injury.
- If the equipment is not functioning properly, fluids or objects have gotten inside, or is otherwise damaged, switch it off immediately and unplug it from the power outlet (if applicable). Only authorized, qualified personnel should repair the equipment.
- Clean the equipment with a dry cloth.
- Comply with all applicable disposal laws and separate plastic and paper/cardboard during packaging disposal.
- Keep plastic bags out of the reach of children.

FOR DEVICES DESIGNED TO BE CONNECTED TO THE MAIN POWER SUPPLY:

- ATTENTION: If your equipment has a power cord with a grounding plug, it must be connected to a wall outlet with a ground connection. Never remove the grounding plug from the power cord.
 - If your equipment has been exposed to extreme temperature changes, allow it to reach room temperature before turning it on. Otherwise, moisture and condensation may damage the equipment.
 - Before plugging in the equipment, make sure that the voltage and frequency of the power outlet match the specifications of the equipment. If the equipment has a voltage selector, only connect it to the power outlet if the values match. If the power cord or adapter does not fit your outlet, contact an electrician.
 - Do not step on the power cord. Make sure it is not pinched at the outlet, adapter, or equipment connection.
 - Keep the power cord or adapter within reach and disconnect the equipment from the power supply when not in use or when cleaning it. Always unplug the cord or adapter by pulling the plug or adapter, not the cord. Never touch the cord or adapter with wet hands.
 - Avoid frequently turning the equipment on and off, as this can reduce its useful life.
 - IMPORTANT: Only replace fuses with those of the same type and rating. If a fuse repeatedly blows, contact an authorized service center.
 - To completely disconnect the equipment from the power mains, unplug the power cord or adapter from the outlet.
 - If your device has a Volex power connector, the mating Volex connector must be unlocked before it can be removed. Be careful when laying cables, as the equipment can slide or fall if the power cord is pulled.
 - Unplug the power cord or adapter before an extended period of disuse or in case of lightning strike risk.
 - Only install the equipment when it is disconnected from the power source.
 - To prevent damage and overheating, qualified personnel should regularly clean and service the equipment depending on ambient conditions like dust, nicotine, and fog.
- If the product contains the following symbols, please, read carefully:



CAUTION: To reduce the risk of electric shock, do not remove cover (or back). There are no user serviceable parts inside. Maintenance and repairs should be exclusively carried out by qualified service personnel.



The warning triangle with lightning symbol indicates dangerous uninsulated voltage inside the unit, which may cause an electrical shock.



The warning triangle with exclamation mark indicates important operating and maintenance instructions.

IMPORTANT INFORMATION**WARNING! IMPORTANT INFORMATION REGARDING LIGHTING PRODUCTS**

1. This product is specifically designed for use in event technology and is not intended to be used as household lighting.
2. It is important to avoid looking directly at the light beam, even for a short period of time.
3. Optical instruments, such as magnifiers, should not be used to look directly at the beam.
4. If you are sensitive to strobe effects, it is possible that they could cause an epileptic seizure. If you have epilepsy, it is important to avoid places where strobe lights are being used.

PACKAGE CONTENT

- 1 x Dallas 300
- 1 x User's manual

PRODUCT DESCRIPTION

- Voltage: AC110-220V 50/60HZ
- Power supply: 300W
- Power: 30 x 10W
- Color: RGBW 4IN1 LEDs
- Channels: 8/4CH
- Operation: DMX512, Auto, Sound, Master-Slave

DISPOSAL

Packaging:



1. The packaging can be recycled using standard disposal methods and reintroduced into the reusable material cycle.
2. Please follow the laws and regulations regarding disposal and recycling of packaging in your country.

Device:



1. This device is subject to the Waste Electrical and Electronic Equipment (WEEE) Directive of the European Union. Used appliances should not be disposed of with household waste. Used device must be disposed of through an approved disposal company or a municipal disposal facility. Please comply with the applicable regulations in your country.
2. Please follow all the disposal laws and regulations in your country.
3. As a customer, you can obtain information on environmentally-friendly disposal options from the product seller or the appropriate regional authorities.

BIENVENIDO A AUDIBAX

Muchas gracias por elegir Audibax. Esperamos que disfrute de su nuevo producto. Ha sido desarrollado y diseñado cuidando hasta el más mínimo detalle, con un control de calidad con estándares europeos supervisado por nuestro gran equipo de técnicos profesionales, que trabajan día a día para ofrecer a nuestros clientes la mejor calidad.

Nos aseguramos de que cada producto Audibax esté diseñado para durar mucho tiempo. Todas nuestras referencias están fabricadas con materiales de larga duración y nuestros especialistas se dedican a realizar constantemente controles de calidad para garantizar el mejor resultado.

Lea atentamente este manual para utilizar su producto Audibax de la mejor manera. No dudes en visitar nuestra web para más información: www.audibax.com


INSTRUCCIONES DE SEGURIDAD

INFORMACIÓN GENERAL

- Es importante leer y seguir las instrucciones cuidadosamente.
- Guarde toda la información y las instrucciones en un lugar seguro.
- Siga siempre las instrucciones proporcionadas.
- Tome nota de todas las advertencias de seguridad y nunca las quite del equipo.
- Utilice el equipo únicamente según lo previsto y para el fin previsto.
- Asegúrese de que los soportes y/o soportes utilizados sean lo suficientemente estables y compatibles para instalaciones fijas. Los soportes de pared deben asegurarse correctamente, y el equipo debe instalarse de forma segura para evitar caídas.
- Al instalar el equipo, asegúrese de observar las normas de seguridad pertinentes de su país.
- No instale ni utilice el equipo cerca de fuentes de calor, como radiadores, rejillas de calor u hornos, y asegúrese de que siempre se enfríe lo suficiente y no se sobrecaliente.
- No coloque fuentes de ignición, como velas encendidas, sobre el equipo.
- Mantenga las ranuras de ventilación despejadas.
- Equipos diseñados solo para uso en interiores y no debe usarse cerca de agua, materiales inflamables, líquidos o gases. Se debe usar para exteriores de acuerdo con las instrucciones del fabricante.
- Asegúrese de que no entren gotas o salpicaduras de agua en el equipo y no coloque recipientes llenos de líquidos sobre el equipo.
- Evite que caigan objetos dentro del equipo.
- Utilice el equipo únicamente con los accesorios recomendados por el fabricante.
- No intente abrir o modificar el equipo.
- Verifique todos los cables después de conectar el equipo para evitar accidentes o daños debido a riesgos de tropiezos.
- Durante el transporte, tome medidas para evitar que el equipo se caiga y cause daños o lesiones.
- Si el equipo no funciona correctamente, se han metido líquidos u objetos en su interior o está dañado, apáguelo inmediatamente y desenchúfelo de la toma de corriente (si corresponde). Solo personal autorizado y cualificado debe reparar el equipo.
- Limpie el equipo con un paño seco.
- Cumpla con todas las leyes de eliminación aplicables y separe el plástico y el papel/cartón durante la eliminación del embalaje.
- Mantenga las bolsas de plástico fuera del alcance de los niños

PARA DISPOSITIVOS DISEÑADOS PARA SER CONECTADOS A LA FUENTE DE ALIMENTACIÓN PRINCIPAL:

- ATENCIÓN: Si su equipo tiene un cable de alimentación con un enchufe con conexión a tierra, debe conectarse a un tomacorriente de pared con conexión a tierra. Nunca retire el enchufe de conexión a tierra del cable de alimentación.
 - Si su equipo ha estado expuesto a cambios extremos de temperatura, permita que alcance la temperatura ambiente antes de encenderlo. De lo contrario, la humedad y la condensación pueden dañar el equipo.
 - Antes de enchufar el equipo, asegúrese de que el voltaje y la frecuencia del tomacorriente coincidan con las especificaciones del equipo. Si el equipo dispone de selector de tensión, sólo conéctelo a la toma de corriente si los valores coinciden. Si el cable de alimentación o el adaptador no se ajustan a su toma de corriente, comuníquese con un electricista.
 - No pise el cable de alimentación. Asegúrese de que no esté pellizcado en la toma de corriente, el adaptador o la conexión del equipo.
 - Mantenga el cable de alimentación o el adaptador al alcance de la mano y desconecte el equipo de la fuente de alimentación cuando no esté en uso o cuando lo esté limpiando. Desenchufe siempre el cable o el adaptador tirando del enchufe o del adaptador, no del cable. Nunca toque el cable o el adaptador con las manos mojadas.
 - Evite encender y apagar el equipo con frecuencia, ya que esto puede reducir su vida útil.
 - IMPORTANTE: Solo reemplace los fusibles con aquellos del mismo tipo y clasificación. Si un fusible se quema repetidamente, comuníquese con un centro de servicio autorizado.
 - Para desconectar completamente el equipo de la red eléctrica, desenchufe el cable de alimentación o el adaptador de la toma de corriente.
 - Si su dispositivo tiene un conector de alimentación Volex, el conector Volex correspondiente debe desbloquearse antes de poder retirarlo. Tenga cuidado al tender los cables, ya que el equipo puede deslizarse o caerse si se tira del cable de alimentación.
 - Desenchufe el cable de alimentación o el adaptador antes de un período prolongado de desuso o en caso de riesgo de caída de rayos.
 - Instale el equipo únicamente cuando esté desconectado de la fuente de alimentación.
 - Para evitar daños y sobrecalentamiento, el personal calificado debe limpiar y reparar el equipo con regularidad según las condiciones ambientales, como polvo, nicotina y niebla.
- Si el producto contiene los siguientes símbolos, lea atentamente:



PRECAUCIÓN: Para reducir el riesgo de descarga eléctrica, no retire la tapa (o la parte trasera). No hay partes reparables por el usuario adentro. El mantenimiento y las reparaciones deben ser realizados exclusivamente por personal de servicio cualificado.



El triángulo de advertencia con el símbolo de un rayo indica un voltaje no aislado peligroso dentro de la unidad, que puede causar una descarga eléctrica.



El triángulo de advertencia con signo de exclamación indica instrucciones importantes de operación y mantenimiento.

INFORMACIÓN IMPORTANTE

¡ADVERTENCIA! INFORMACIÓN IMPORTANTE SOBRE PRODUCTOS DE ILUMINACIÓN

1. Este producto está diseñado específicamente para su uso en tecnología de eventos y no está diseñado para usarse como iluminación doméstica.
2. Es importante evitar mirar directamente al haz de luz, incluso durante un breve período de tiempo.

- No se deben utilizar instrumentos ópticos, como lupas, para mirar directamente al haz.
- Si es sensible a los efectos estroboscópicos, es posible que le provoquen un ataque epiléptico. Si tiene epilepsia, es importante evitar los lugares donde se usan luces estroboscópicas.

CONTENIDO DEL PAQUETE

- 1 x Dallas 300
- 1 x Manual de usuario

DESCRIPCIÓN DEL PRODUCTO

- Voltaje: AC110-220V 50/60HZ
- Fuente de energía: 300W
- Potencia: 30 x 10W
- Color: RGBW 4IN1 LEDs
- Canales DMX:8/4CH
- Funcionamiento: DMX512, Auto, Sonido, Maestro-Esclavo

RECICLAJE

Embalaje:



- El embalaje puede ser reciclado utilizando métodos de eliminación estándar y reintroducido en el ciclo de materiales reutilizables.
- Por favor, sigue las leyes y regulaciones relativas a la eliminación y el reciclaje del empaque en tu país.

Dispositivo:



- Este dispositivo está sujeto a la Directiva de Residuos de Equipos Eléctricos y Electrónicos (WEEE) de la Unión Europea. Los aparatos electrónicos usados no deben ser eliminados con los residuos domésticos. Los dispositivos usados deben ser eliminados a través de una empresa de eliminación aprobada o una instalación de eliminación municipal. Por favor, cumple con las regulaciones aplicables en tu país.
- Por favor, sigue todas las leyes y regulaciones de eliminación en tu país.
- Como cliente, puedes obtener información sobre opciones de eliminación respetuosas con el medio ambiente del vendedor del producto o las autoridades regionales apropiadas.

DMX (English)**DMX512 control: 8 channel mode (A001)**

Channel	Function	Description
CH1	Master dimmer	R, G, B, W dimmer: from dark to bright
CH2	R attenuator	Red: dark to bright
CH3	G dimmer	Green: from dark to bright
CH4	B attenuator	Blue: from dark to bright
CH5	W dimmer	White: dark to bright
CH6	Strobe	R, G, B, W strobe: slow to fast
CH7	Function	0-50: DMX 8CH Control. 51-100: Color Selection 101-150: Auto color change (jump). 151-200: Auto color change (fade). 201-250: Auto color change (pulse). 251-255: Sound Activation
CH8	Function speed	Speed: from slow to fast

DMX512 control: 4 channel mode (D001)

Channel	Function	Description
CH1	R dimmer	Red: dark to bright
CH2	G dimmer	Green: from dark to bright
CH3	B dimmer	Blue: from dark to bright
CH4	W dimmer	White: from dark to bright

INTERNAL FUNCTIONS:

1	d001	DMX address (001-512)	DMX address, 4 channel mode
2	A001	DMX address (001-512)	DMX address, 8 channel mode
3	r255	Red (000-255)	UP, DOWN Change Brightness
4	G255	Green (000-255)	UP, DOWN Change Brightness
5	b255	Blue (000-255)	UP, DOWN Change Brightness
6	u255	White (000-255)	UP, DOWN Change Brightness
7	FH99	Strobe (Flash) (01-99)	UP, DOWN Change Brightness
8	CL01	Color Selection (01-08)	UP, DOWN Change Color
9	CC99	Color Change (Jump) (01-99)	UP, DOWN Change Speed
10	DE99	Color Change (Fade) (01-99)	UP, DOWN Change Speed
11	CP99	Color Change (Pulse) (01-99)	UP, DOWN Change Speed
12	SU01	Sound Activated Color (01-09)	UP, DOWN Changes the effect

DMX (Español)**Control DMX512: Modo 8 canales (A001)**

Canal	Función	Descripción
CH1	Atenuador general	R, G, B, W atenuador: de oscuro a brillante
CH2	R atenuador	Rojo: de oscuro a brillante
CH3	G atenuador	Verde: de oscuro a brillante
CH4	B atenuador	Azul: de oscuro a brillante
CH5	W atenuador	Blanco: de oscuro a brillante
CH6	Estrobo	R, G, B, W estrobo: de lento a rápido
CH7	Función	0-50: DMX 8CH Control. 51-100: Selección Color 101-150: Cambio de color auto (salto). 151-200: Cambio de color auto (fundido). 201-250: Cambio de color auto (pulso). 251-255: Activación por sonido
CH8	Velocidad de Función	Velocidad: de lento a rápido

Control DMX512: Modo 4 canales (D001)

Canal	Función	Descripción
CH1	R atenuador	Rojo: de oscuro a brillante
CH2	G atenuador	Verde: de oscuro a brillante
CH3	B atenuador	Azul: de oscuro a brillante
CH4	W atenuador	Blanco: de oscuro a brillante

FUNCIONES INTERNAS:

1	d001	Dirección DMX (001-512)	Dirección DMX, modo 4 canales
2	A001	Dirección DMX (001-512)	Dirección DMX, modo 8 canales
3	r255	Rojo (000-255)	UP, DOWN Cambia Brillo
4	G255	Verde (000-255)	UP, DOWN Cambia Brillo
5	b255	Azul (000-255)	UP, DOWN Cambia Brillo
6	u255	Blanco (000-255)	UP, DOWN Cambia Brillo
7	FH99	Estrobo (Flash) (01-99)	UP, DOWN Cambia Brillo
8	CL01	Selección Color (01-08)	UP, DOWN Cambia Color
9	CC99	Cambio Color (Salto) (01-99)	UP, DOWN Cambio Velocidad
10	DE99	Cambio Color (Fundido) (01-99)	UP, DOWN Cambio Velocidad
11	CP99	Cambio Color (Pulso) (01-99)	UP, DOWN Cambio Velocidad
12	SU01	Color Activado por Sonido (01-09)	UP, DOWN Cambia el efecto

DATA SHEET

- Brand: Audibax
- Product Name: Dallas 300
- ID: 10146782
- EAN: 637913209390
- Category: Lighting Par Spotlights
- Lamp Type: Led
- Power: 300W
- Number of LEDs: 30
- Power Per LED: 10W
- Color Mix: RGBW
- Exterior Use: No
- Battery Operation: No
- Housing Type: Aluminum
- Housing Color: Black
- Wireless Control: No
- Opening Angle: 30°
- Connections: 3 Pin XLR
- Height: 32 cm
- Width: 32 cm
- Depth: 12 cm
- Motorized Focus: No
- Remote Control: No
- Control by App: No
- DMX control: Yes